

**NOT FOR HOME
USE**


Owner's Manual For:

JARVIS Wellsaw

PORTABLE POWER SAW

MODEL 404

Table Of Contents	Page
•Parts Diagram	2
•Parts List	3
•Notice to Employer and Safety Director	4
•Notice to Operators, Maintenance and Cleanup Personnel	5
•Installation Instructions	6
•Operation Instructions	7
•Maintenance Instructions	8
•General Safety Instructions	10




JARVIS[®]

6205006::

PRODUCTS CORPORATION

33 ANDERSON ROAD, MIDDLETOWN, CONNECTICUT 06457-4926
UNITED STATES OF AMERICA
FAX 860-347-6978 TEL. 860-347-7271



JARVIS®

6205008::

PRODUCTS CORPORATION

33 ANDERSON ROAD, MIDDLETOWN, CONNECTICUT 06457-4926

UNITED STATES OF AMERICA

FAX 860-347-6978 TEL. 860-347-7271

ITEM	JARVIS PART NO.	OLD PART NO.	PART NAME	QTY
1	1063112	501022-005	brush cap	2
2	1063111	501022-004	brush and spring	2
3	1063110	501022-003	brush holder	2
4	1015006	501174	deflector	2
5	1002191	501002	top cap	1
6	1055428	100101-004	screw	4
7	1021215	100403-003	ball bearing	1
8	1063119	501224-003	stator 115v	1
8	1063120	501224-004	stator 230v	1
9	1027040	501021	stator stud	2
10	1007164	100105-001	locknut	4
11	1063117	501224-001	armature 115v	1
11	1063118	501224-002	armature 230v	1
12	1026072	501225	pinion	1
13	1021227	100422-004	ball bearing	1
14	1035193	501120-001	seal	1
15	1016199	501001-006	housing	1
	1017033	501178	info label 115v, English	1
	1017034	501179	info label 230v, English	1
	1017054		info label 115v, French	1
	1017234		info label 230v, French	1
16	1063109	100647	grommet	1
17	1013137	501295	clamp ring	1
18	1063125	501294	strain relief	1
19	3001008	501006	cord & plug 115v	1
19	3001011	501337	cord & plug 230v	1
19	3001017		European line cord	1
20	1055438	100101-003	screw, set of 12	3
21	1005038	100739-001	switch	1
22	1007166	501376	gear stud nut	1
23	1004149	100426-001	thrust bearing race	1
24	1021218	100425-001	needle thrust bearing	1
25	1020133	501377	gear stud	1
26	1514502	100069-013	snap ring	1
27	1021216	100424-001	needle bearing	2
28	1027043	501081	drive stud	1
29	3026024	501223	gear & stud	1
30	1029185	501082	spacer	1
31	3028030	501053	connecting rod & bearing	1
32	1035191	501008	gasket	1
33	1002193	501005	bottom plate	1
34	1055426	100101-001	screw, set of 12	4
35	1062003		gear grease 16 oz.	1
36	1002203	501004	handle cover	1
37	1055439	100102-002	screw	5
38	1002206	501003-001	blade support clamp	1
39	1036120	501273	insert bushing	3
40	1027048	501272	stud	3
41	1007162	100022-006	cap nut	6
42	1012047	501043	"u" clip (rubber)	1
43	1012046	501042	"s" clip	1
44	8030031	100099-001	hex key	1

ITEM	JARVIS PART NO.	OLD PART NO.	PART NAME	QTY
45	1035192	501103	seal	1
46	1036116	501171	bushing	1
47	1027041	501046	rod stud	1
48	3065010	501172	push rod & stud	1
49	1012050	501350	push rod ring	1
50	1055422	100034-038	set screw 1/4	1
51	1006021	501066	knob	1
52	1027042	501065	handle stud	1
52	1027049	501378	handle stud, heavy duty	1
53	1055429	100102-003	screw	2

blades, blade supports
and accessories

ITEM	JARVIS PART NO.	OLD PART NO.	PART NAME	QTY
54	1058071	501175T	blade support 8" end cut.	1
56	1058075	502077T	blade sup. 8" heavy duty	1
54	1058070	501128T	blade support 16" end cut.	1
56	1058074	502076T	blade sup. 16" heavy duty	1
55	1023122	501246	blade 8" end cutting	1
57	1023123	501319	blade 8" heavy duty	1
55	1023121	501247	blade 16" end cutting	1
57	1023124	501320	blade 16" heavy duty	1

replacement kits

ITEM	JARVIS PART NO.	OLD PART NO.	PART NAME	QTY
	3063010	501351-001	armature and bearing (no pinion) 115v	
	3063011	501351-002	armature and bearing (no pinion) 230v	
	3063007	501235-001	armature, bearing and pinion 115v	
	3063008	501235-002	armature, bearing and pinion 230v	
	3063013	501232	armature and pinion 115v	
	3063014	501233	armature and pinion 230v	
	3001008	501006	cord assembly 115v	
	3001010	501089	cord assembly 230v	
	3026023	501088	gear & bearing assembly	
	3016119	501169-001	housing & bushing assy.	

JARVIS®

6205006..

PRODUCTS CORPORATION

33 ANDERSON ROAD, MIDDLETOWN, CONNECTICUT 06457-4926
UNITED STATES OF AMERICA
FAX 860-347-6978 TEL. 860-347-7271